






POSITION of SENSORS

M.V. Peggy Dow

PEGGY DOW



○ AIR RELATIVE HUMIDITY SENSOR
 ● AIR TEMPERATURE SENSOR
 □ AIR TEMPERATURE SENSOR