

CODE NUMBER SIGNIFICATION

THE FIRST CODE FIGURE:

- 1 = HATCH 1
- 2 = " 2
- 3 = " 3
- 4 = " 4
- 5 = SEA WATER SYSTEM
- 6 = FREON SYSTEM
- 7 = BRINE SYSTEM
- 8 = VARIOUS

THE SECOND CODE FIGURE:

IF THE FIRST FIGURE IS 1, 2, 3, OR 4

- 1 DECK A
- 2 " B
- 3 " C
- 4 " D
- 5 " E

IF THE FIRST FIGURE IS 5 OR 6

- 1 COMPR 1
- 2 " 2
- 3 " 3
- 4 VARIOUS

IF THE FIRST FIGURE IS 7

- 1 BRINE SYSTEM 1 (YELLOW)
- 2 " 2 (BLUE)
- 3 " 3 (RED)

IF THE FIRST FIGURE IS 8 OR 9

- 0 OUTDOOR
- 1 COMPR 1
- 2 " 2
- 3 " 3
- 4-9 VARIOUS


THE THIRD CODE FIGURE:

- 0-3 = TEMP
- 4-5 = PRESSURE
- 6 = HUMIDITY
- 7 = LEVEL
- 8-9 = VARIOUS


THE FOURTH CODE FIGURE:

ROOM 2



A




B



C




D




E

ROOM 3



A




B



C




D




E

ROOM 4


A



B



C



SYMBOLS	
△	FIXED TEMP. SENSOR LENGTH 4 M
△	BASE FOR PORTABLE TEMP. SENSOR LENGTH 12 M
○	DELIVERY TEMP. SENSOR
⊗	RETURN TEMP. SENSOR
□	DIFFERENTIAL PRESSURE TRANSMITTER
○	HUMIDITY TRANSMITTER