




A






B



C



D



- 1 A/B Recorder # 1
- 2 C/D, 3 A/B, 3 C/D Recorder # 2
- 3 4A, 4B/C Recorder # 3

□ SHOWS FIXED SENSOR

○ SHOWS NON-FIXED SENSOR

M/S SAKURA REEFER



OSAKA JAPAN