

LOCATION OF TEMPERATURE SENSORS USDA

SARAMATI
Hull No. 835

△	43	USDA TEMP. SENSOR PORTABLE 12M WIRE
△	20	USDA FIXED TEMP. SENSOR 4M WIRE SHOULD BE LOCATED ON THE CENTER LINE OF THE VESSEL APPROXIMATELY 30CM FROM THE CEILING. SHOULD BE ATTACHED IN SUCH A WAY THAT THEY DO NOT TOUCH THE BULKHEAD AND ARE PROTECTED FROM DAMAGE FROM THE CARGO.

