

Scamper

Scamper
Hull No. 193

454	455	456	457	452	x	405	406	354	355	356	314	315	316
x	x	x	x	x	x	x	x	x	x	x	x	x	x
402	403	407	x	353	x	352	x	354	x	355	x	312	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
541	541	3A	407	x	353	2A	357	x	313	x	311	1A	317

4A	x	x	x	x	x	408	409	x	x	x	x	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
451	451	x	x	x	x	x	x	x	x	x	x	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
451	451	x	x	x	x	x	x	x	x	x	x	x	x

474	475	476	472	415	416	364	365	366	324	325	326	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
x	4B	547	542	3B	417	x	362	x	322	x	323	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
471	x	471	411	41.8	41.9	41.0	363	364	367	x	321	1B	327

478	x	479	424	425	426	374	375	376	334	335	x	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
423	423	3C	422	x	322	x	322	x	332	x	333	1C	336
x	x	x	x	x	x	x	x	x	x	x	x	x	x
421	421	428	429	420	321	x	321	x	331	x	332	x	x

484	485	486	482	435	436	374	375	376	334	335	x	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
483	483	483	483	432	x	322	x	322	332	x	333	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
481	481	481	481	431	432	321	321	322	331	x	332	x	x

487	488	489	488	438	439	374	375	376	334	335	x	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
491	491	491	491	431	432	321	321	322	331	x	332	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
492	492	492	492	431	432	321	321	322	331	x	332	x	x

494	x	492	493	434	435	384	385	386	344	x	342	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
493	493	493	493	433	434	383	384	385	343	x	341	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
491	491	491	491	431	432	381	382	383	341	x	340	x	x

497	x	498	x	434	435	384	385	386	344	x	342	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
498	498	498	498	432	433	382	383	384	342	x	340	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x
499	499	499	499	431	432	381	382	383	341	x	340	x	x

x - SPACE SENSOR
 ⊕ - AIR SUPPLY
 □ - AIR RETURN
 ■ - HUMIDITY