





NV "SPRING TIGER"





TEMP SENSORS INDICATED WITH THIS SHIP'S	TEMP SENSORS WHICH ARE LISTED ON THE SECOND FIGURE IS 1, 2, 3 OR 4 STATES IF THE FIRST FIGURE IS 1 OR 2 THE STATES CORRESPOND TO LIST OF 3
DELIVERY CONTROL TEMP	DELIVERY TEMP
RETURN CONTROL TEMP	RETURN TEMP
MISCELLANEOUS	
SERIAL NUMBER	IF THE FIRST FIGURE IS LISTED ON THE FOURTH FIGURE IS LISTED ON THE LOCATION LIST OF STATES PORT

SYMBOLS	
○	DELIVERY CONTROL SENSOR ROT OR
⊗	DELIVERY TEMP SENSOR
⊙	RETURN TEMP SENSOR
△	FIXED TEMP SENSOR WSDA LIST
▽	BASE FOR PORTABLE TEMP SENSOR



HEATING POINT LIST	DATE/COLOR	NO IN DATA
CORNING WATER TEMP INLET COMP	5101	5101
CORNING WATER TEMP OUTLET COMP	5102	5102
BOILING WATER TEMP OUTLET COMP	5103	5103
SEA SUPERHEATING TEMP EVAP	5104	5104
SEA SUPERHEATING TEMP EVAP	5105	5105
SEA SUPERHEATING TEMP EVAP	5106	5106
DISCHARGE TEMP	5107	5107
CONDENSING TEMP	5108	5108
SEA WATER TEMP	5109	5109
AMBIENT	5110	5110
BRINE HEATER	5111	5111
BRINE SYSTEM BLUE CONTROL	5112	5112
BRINE SYSTEM YELLOW CONTROL	5113	5113
GROUP ALARM		



LOCATION OF TEMPERATURE  
IN CARGO HOLD