

Ub Prince
Hull No. 83

Skala:
Tegn: 26.9.76
Ktr. T.M.

F4-2131-83










BAHNAS EMMANUEL C

Arrangement of Resistance Thermometers and Humidity Detectors in Cargo Holds

Arr. av motstandstermometere og fuktighetsmålere i lasterom.

DRAMMEN SLIP & VERKSTED

| Hold No Laster no. | Portable feelers | | Portable feelers av innet. | | Humidity feelers | |
|-----------------------|------------------|------|-------------------------------|------|----------------------|------|
| | Transp.sølere | | Transp.sølere innegsluft. | | Fuktighets målere | |
| 1FC | 0121 | 0122 | 0123 | 0124 | 0170 | 0170 |
| 1A | 0221 | 0222 | 0223 | 0224 | 0270 | 0270 |
| 1B | 0321 | 0322 | 0323 | 0324 | 0370 | 0370 |
| 1C | 0421 | 0422 | 0423 | 0424 | 0470 | 0470 |
| 1D | 0521 | 0522 | 0523 | 0524 | 0570 | 0570 |
| 2A | 0621 | 0622 | 0623 | 0624 | 0670 | 0670 |
| 2B | 0721 | 0722 | 0723 | 0724 | 0770 | 0770 |
| 2C | 0821 | 0822 | 0823 | 0824 | 0870 | 0870 |
| 2D | 0921 | 0922 | 0923 | 0924 | 0970 | 0970 |
| 3A | 1021 | 1022 | 1023 | 1024 | 1070 | 1070 |
| 3B | 1121 | 1123 | 1124 | 1125 | 1120 | 1170 |
| 3C | 1221 | 1222 | 1223 | 1224 | 1220 | 1270 |
| 4A | 1321 | 1322 | 1323 | 1324 | 1320 | 1370 |
| 4B | 1421 | 1422 | 1423 | 1424 | 1420 | 1470 |
| 4C | 1521 | 1522 | 1523 | 1524 | 1520 | 1570 |



SYMBOLS:
● Portable feelers.
■ Humidity feelers.